





Factsheet: updated 14 May 2008

Fuses



Interior Fuses

Fuse Number	All Models Up To September 2001	Models After September 2001
1	Cabin (10a)	Cabin (10a)
2	Hazard Lights (10a)	Hazard Lights (10a)
3	Brake Lights (15a)	Brake Lights (15a)
4	Central Locking (30a)	Central Locking (30a)
5	Horn (10a)	Rear lights (10a)
6	Blinds:- passenger side (15a)	Blinds:- passenger side (15a)
7	Blinds:- driver side (15a)	Blinds:- driver side (15a)
8	Cigar lighters, mirrors, radio (15a)	Cigar lighters, mirrors, radio (15a)
9	Engine Management System (15a)	Engine Management System (15a)
10	Dashboard (15a)	Dashboard (15a)
11	Indicators (10a)	Indicators (10a)
12	AFT Roof (30a) or Sun Roof (20a)	AFT Roof (30a) or Sun Roof (20a)
13	Rear wipers & washers (20a)	Rear wipers & washers (20a)
14	Electric windows (30a)	Electric windows (30a)
15	Front wipers and washers (20a)	Front wipers and washers (20a)
16	Aircon (10a)	Aircon (10a)
17	Sliding Door (15a)	Sliding Door (15a)
18	Glow plugs (10a)	Headlamps (20a)
19	Additional equipment	Additional equipment
20	Rear demister (30a)	Additional equipment
		(Spaces on bottom row used for dipped beam-Xenon option)



Bonnet Fuses

Fuse Number	Petrol Up To Sept 01	Petrol After Sept 01	Diesel Up To Sept 01	Diesel After Sept 01
1	Engine Management (30a)	Main Fuse (100a)	Engine Fan 2 (40a)	Main Fuse (100a)
2	Radiator Fan (30a)	Head Lamps (30a; 40a if Xenon)	Cooling Fan (30a)	Head Lamps (30a; 40a if Xenon)
3	Head Lamps (30a)	Radiator Fan (30a)	Head Lamps (30a)	Radiator Fan (30a)
4	Main Fuse (100a)	Engine Management (30a)	Main Fuse (100a)	Radiator Fan (40a)
5				Starter Motor (10a)
6	Starter Motor (10a)	Starter Motor (10a)	Starter Motor (10a)	Glowplugs (20a)
7	ABS (20a)	ABS (20a)	ABS (20a)	ABS (20a)
8	Rear Lights (15a)	AC Power (15a)	Rear Lights (15a)	AC Power (15a)
9			Fuel Pump & ECU (10a)	Fuel Pump & ECU (15a)
10	Front Fog Lamps (15a)	Front Fog Lamps (15a)	Front Fog Lamps (15a)	Front Fog Lamps (15a)
11				
12				
13	Ignition (60a)	Ignition (60a)	Ignition (60a)	Ignition (60a)
14	ABS (60a)	ABS (60a)	ABS (60a)	ABS (60a)
15	Rear Heater (30a)	Rear Heater (30a)	Rear Heater (30a)	Rear Heater (30a)
16	Cabin, Central Locking (40a)	Cabin, Central Locking (40a)	Cabin, Central Locking (40a)	Cabin, Central Locking (40a)
17	Heating (30a)	Heating (30a)	Heating (30a)	Heating (30a)
18	Engine Fan (30a)	Engine Fan (30a)	Engine Fan (30a)	Engine Fan (30a)

© **Bongo Fury 2008**. For the sole use of members of Bongo Fury, the Mazda Campervan Owners' Club. Not to be reproduced or passed on, in whole or in part, without permission. The Bongo Fury logo is protected by copyright.

Important legal disclaimer: the views expressed in this factsheet are those of the contributor(s) and do not constitute professional advice from Bongo Fury, the Mazda Campervan Owners' Club. Bongo Fury cannot be held responsible for any vehicle damage, injury or financial liability, whether to yourself or others, incurred directly or indirectly as a result of following the advice given in this factsheet. If in doubt contact a qualified professional or your local service centre.